

IMPORTANT SAFEGUARDS READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

When using electrical equipment, basic safety precautions should always be followed including the following:

- **DISCONNECT AC POWER SUPPLY BEFORE SERVICING.**
- Installation and servicing of this equipment should be performed by qualified service personnel only.
- Equipment should be mounted in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- Any modification or use of non-original components will void the warranty and product liability.
- Do not use this equipment for other than intended use.

SAVE THESE INSTRUCTIONS!

Technical Support ■ (623) 580-8943 ■ technicalsupport@barronltg.com

Panel Replacement

1. To remove the old panel, loosen one side by pulling down. It may be necessary to insert a flat tool between the panel and the spring clip, as shown, in order to release the panel from the spring clip housed within the light bar.
2. Carefully swing the panel down and pull the other end away from the light bar to remove.
3. To install the new panel, align one notch with the spring clip in one side of the light bar.
4. Swing the other end up, then push the panel firmly in place within the light bar until the spring clip locks within the notch. Check to be sure that the panel is properly secured within the light bar by lightly pulling down on the panel.

NOTE: Always wear gloves when handling the acrylic panels to prevent the formation of smudge marks.

