


# Phoenix Lite Series

Components



1. Input Transformer
2. Input Terminal Blocks
3. Output Terminal Blocks
4. Output Transformer
5. Battery Terminal Blocks
6. Fan
7. Batteries
8. Power ON/OFF Display
9. Main Input Breaker (CB1)
10. Main Output Breaker (CB3)
11. Main Power Board